

Chapter 4 – Supported Software

4.1. Software Installation Steps

Insert the CD that will be autorun after insertion into CD driver, select the items that need to be installed. We provide auto installation of the various drivers for mainboard, graphics, and sound. You can follow the instructions shown on the monitor step by step to complete your installation.

STEP 1:

AUTORUN PICTURE 1

[Mainboard] [PC-cillin] [DirectX]
Select “**Mainboard**” item.

STEP 2:

Slot1 Mainboard Products Page

[ALI Series Mainboard Products]
[VIA Series Mainboard Products]
[SiS Series Mainboard Products]
Select “**VIA Series Mainboard Products**” item.

STEP 3:

MAINBOARD Page

[Slot1 Mainboard Products]
[Socket370 Mainboard Products]
[Socket7 Mainboard Products]
Select “**Slot1 Mainboard Products**” item.

STEP 4:

VIA Series Mainboard Products Page

Select “**Slot1 VIA693-133 ATX Mainboard**” model.

STEP 5:

“STEP 4” Mainboard Page

[MAINBOARD] item

Chapter 4 – Supported Software

4.2. Mainboard Installation

4.2.1. System Hardware Monitor Setup Utility(Optional)

The mainboard comes with a system health monitor utility contained in the provided CD. This utility shows the current temperature of the processor, power voltages, and processor / chassis fan speed.

The utility also allows you to manually set the range of the processors temperature, power voltages, and processor / chassis fan speed. If the values of setting are over or under the set range, an error message will pop-up and an alarm will go off. This software driver supports the following OS: Microsoft Windows 9X and Windows NT

4.2.2. IDE Bus Master Driver

The mainboard comes with IDE Bus Master driver which supports the following OS: Windows 9X and O/SR2. To install the IDE driver, please refer to the "Readme" file contained in the provided CD.

4.3. Trend OEM English PC-Cillin

This Trend PC-cillin (OEM-English) is for Windows 9X. To installed select Auto Run "PC-cillin", please refer to the "Readme" file contained in the provided CD. For optimum protection against viruses, you must continue to update your virus pattern file, which is used by PC-cillin to detect virus activity. You can download pattern files from either the Internet or BBS after you register the product.

Technical support is available to registered users at Trend offices worldwide. To find a Trend Office nearest you, look in the tech.txt file in the program group or under the Technical Support topic in the on-line help or user's guide. You can also find the address of a Trend office near you from our Web site at:

Web Page <http://www.antivirus.com> or www.trend.com.tw